

How to Measure your Windows for Ecoease Secondary Glazing

Please follow these 3 handy tips for measuring your windows.

1. Use the right measuring tape:



Use a metal tape measure. Cloth ones can stretch or bend which can make your measurements harder to get right. It needs to have metric measurements. The website is not set up for imperial ones.

A simple metric guide:

1 centimetre = 10mm e.g. 30cm = 300mm (just add a 0!)
1 metre = 1000mm e.g. 1.2m = 1200mm

2. Give names to the windows you are about to measure. e.g.



Main bedroom: 1200mm x 398mm

Bathroom: 1,150mm x 498mm

There is a place on the website for you to easily record them and if you are ordering a number of panels it will help when it comes to fitting the windows. It avoids you having to re-measure anything.

3. Ecoease glazing fits on the inside of the window frame.

Measure the height and width to the outside edge of the frame.

Not all windows are 'square' or 'straight' so measure both the width and height from each corner or end. e.g.

top measurement = 997 mm


bottom measurement = 1000 mm

N.B. **Always** give us the smaller of these two measurements



Make sure that any window architecture, such as window handles or locks, do not protrude above the depth of the window frame you are measuring and Ecoease glazing will be fitted to.



N.B. Ecoease glazing is made of PET  which is flexible, so if a handle or lock is a millimetre or so over the window frame this will still work OK but is not ideal visually.