Fitting tips for Made To Measure panels

Thank you very much for ordering our Made to Measure Secondary Glazing panels.

While Ecoease secondary glazing is very easy to fit, the following information will guide you through:

- Before you remove the protective film on your panel offer it up to the window to check it will fit.

- To ensure the magnetic tapes adhere properly to your window frame, wipe your frame a degreaser e.g. methylated spirits or similar.

- Slowly remove the protective film on the side of the panel with the tapes attached - the one which face the glass of your window. If you remove the film too quickly you will create static electricity which will attract dust and other minute debris. Leave the film on the surface which faces the room for the moment.

- **Peel of the backing from the back of the blue steel tape. Never remove the white steel tape and stick onto the window frame on its own. You will NEVER match it up with the magnetic tapes properly if you do this and the glazing will not fully magnetically attach.**

- You can now offer the panel up to your frame. It can help to use your window cill to balance the panel allowing you to “walk” it up to the window.

- When your Secondary Glazing pane is in place, press with your thumb along the white PVC edging to ensure it is securely fixed all around. Press this firmly all along the length of the tape as the adhesive bonds when firm pressure is applied. This firm pressure is needed to fully activate the adhesive.

- Finally, slowly remove the film from the front of the panel.