

Fitting tips for Made to Measure panels

Thank you very much for ordering our Made to Measure Secondary Glazing panels. While secondary glazing is very easy to fit, the following information will guide you through:

- Before you remove the protective film on your panel offer it up to the window to check it will fit.
- To ensure the adhesive on the magnetic tapes adhere properly to your window frames, wipe them thoroughly with a degreaser e.g. methylated spirits or similar.
- Slowly remove the protective film on the side of the panel with the tapes attached. This one will face the glass of your window. If you remove the film too quickly you will create static electricity which will attract dust and other minute debris. Leave the film on the surface which faces the room for the moment.
- Check if the steel tapes (the ones with the blue backing) have moved during transit. Realign them with the magnetic tape if necessary and remove the blue backing film. Never attempt to remove the steel strips and stick them to your window frame. If you do this you will have difficulty lining them up properly again!
- You can now offer the whole panel up to your frame. It can help to use your window cill to balance the panel allowing you to “walk” it up to the window.
- When your Secondary Glazing pane is in place, press firmly with your thumb along the white PVC edging to ensure it is securely fixed all around. This is important as the tapes have a contact adhesive that activates with pressure for a firm fix.
- Finally, slowly remove the film from the front of the panel.

Cleaning your solid polycarbonate panels:

When you need to clean your panels use a weak mixture of mild soapy water and a damp cloth such as microfibre. Never use a dry cloth or anything abrasive to clean the polycarbonate panels.