



**Fitting Instructions for The Boughton  
Apex 2-piece Canopy**

**STEP 1**

- A: Mark centre-line onto door frame.
- B: Mark spirit level line – do not cover any weep holes.

**STEP 2**

- C: Mark centre-line on canopy soffit.
- D: 1<sup>st</sup> operative to offer soffit to wall marrying up all marks.

**STEP 3**

- E: 2<sup>nd</sup> operative to drill 6.5x120mm tight to both ends (central) Fix using 7.5x100mm concrete fixing with oversize mudguard washer.

**STEP 4**

- F: Use spirit level to check canopy is level on projection.
- G: Pack between back of canopy and wall where required. Tighten/slacken fixing if necessary.

**STEP 5**

- H: Once canopy is all level, put fixings along rest of back into wall at max 400mm (equal spacing)
- I: Use spirit level to double check (loosen & pack if necessary)



## STEP 6

J: Mark and pre-drill roof part of canopy along back flange at max. 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

## STEP 7

K: Offer roof to soffit – pin fasteners to meet holes in soffit.

L: Drill (6.5x120mm bit) through pre-drilled holes (J) and into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive caps.

## STEP 8

M: Before fixing tight, packers may be necessary between roof flange and brickwork to prevent canopy going out of level.

N: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

O: Cover all visible screw heads with colour matching caps or lead flash into brickwork and over flange (optional).



the  
**glazing**shop

Tel: 01536 446395 Email: [sales@theglazingshop.co.uk](mailto:sales@theglazingshop.co.uk) Web: [www.theglazingshop.co.uk](http://www.theglazingshop.co.uk)

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX