

# Munting Bar Fixing Instructions

1 Lay the aluminium extrusion between glazing bars.




3 Run finger along glazing connector to remove excess silicone.



4 Lay first glazing panel onto glazing connector.




6 Without using excess force gently bend the sides of the PVC connector cap towards you.



8 Run finger along PVC connector cap to remove excess silicone.



10 Press firmly until PVC connector cap engages into the channels of the aluminium glazing connector.



*Please note:  
For wider spans, it may help with engagement of the PVC connector cap if a 2<sup>nd</sup> person supports the aluminium glazing connector from underneath.*

2 Apply a narrow band of low modulus silicone sealant along both sides of the aluminium glazing connector.




*Please note:  
If using a self cleaning glass a polymer based silicone must be used.*

5 Lay second glazing panel onto glazing connector.



7 Apply a narrow bead of silicone along both sides of the PVC connector cap.




9 Put PVC connector cap in place above the aluminium glazing connector.



11 Still pressing down firmly, move your hand and thumb along the remainder.



12 With a cloth wipe off excess silicone.



13 Fixing complete.

**01536 446395**

[www.theglazingshop.co.uk](http://www.theglazingshop.co.uk)

the  
**glazing** shop